



Grewin

**TIANJIN GREWIN TECHNOLOGY CO.,LTD.**

Web:[www.grewin-tech.com](http://www.grewin-tech.com) WhatsApp:+86-13072088960

Email:[salesmanager@grewin-tech.com](mailto:salesmanager@grewin-tech.com)

## Transformer For Medical Equipment



Tianjin Grewin Technology Co.Ltd

Web:[www.grewin-tech.com](http://www.grewin-tech.com) .

Add:DongLi Distr Tianjin City, China

Phone: +86-22-84943756

WhatsApp:+86-13072088960

Email:[salesmanager@grewin-tech.com](mailto:salesmanager@grewin-tech.com)



# TIANJIN GREWIN TECHNOLOGY CO.,LTD.

Web:www.grewin-tech.com WhatsApp:+86-13072088960

Email:salesmanager@grewin-tech.com

Power	Thermal Fuse	Current Fuse	Dimension (A*Bmm)	Approval Mark
25W	135°C 250V2A	250V T 2A	80*35	UL CE TUV CQC
30W	135°C 250V2A	250V T 2A	83*35	UL CE TUV CQC
40W	135°C 250V2A	250V T 2A	87*35	UL CE TUV CQC
50W	135°C 250V2A	250V T 2A	93*34	UL CE TUV CQC
60W	135°C 250V2A	250V T 2A	93*35	UL CE TUV CQC
80W	135°C 250V2A	250V T 2A	102*35	UL CE TUV CQC
105W	135°C 250V2A	250V T 2A	114*38	UL CE TUV CQC
120W	135°C 250V2A	250V T 2A	113*41	UL CE TUV CQC
140W	135°C 250V2A	250V T 2A	114*42	UL CE TUV CQC
150W	135°C 250V2A	250V T 2A	117*43	UL CE TUV CQC
160W	135°C 250V5A	250V T 5A	120*43	UL CE TUV CQC
180W	135°C 250V5A	250V T 5A	125*42	UL CE TUV CQC
200W	135°C 250V5A	250V T 5A	124*49	UL CE TUV CQC
220W	135°C 250V5A	250V T 5A	127*50	UL CE TUV CQC
240W	135°C 250V5A	250V T 5A	129*48	UL CE TUV CQC
250W	135°C 250V5A	250V T 5A	130*52	UL CE TUV CQC
260W	135°C 250V5A	250V T 5A	130*53	UL CE TUV CQC
280W	135°C 250V5A	250V T 5A	138*45	UL CE TUV CQC
300W	135°C 250V5A	250V T 5A	138*54	UL CE TUV CQC
320W	135°C 250V5A	250V T 5A	138*54	UL CE TUV CQC
340W	135°C 250V5A	250V T 5A	138*54	UL CE TUV CQC
360W	135°C 250V5A	250V T 5A	142*55	UL CE TUV CQC
380W	135°C 250V5A	250V T 5A	146*54	UL CE TUV CQC
400W	135°C 250V5A	250V T 5A	148*56	UL CE TUV CQC
420W	135°C 250V5A	250V T 5A	148*56	UL CE TUV CQC
440W	135°C 250V5A	250V T 5A	148*60	UL CE TUV CQC
460W	135°C 250V5A	250V T 5A	149*64	UL CE TUV CQC
480W	135°C 250V5A	250V T 5A	153*59	UL CE TUV CQC
500W	135°C 250V5A	250V T 5A	155*62	UL CE TUV CQC



Grewin

**TIANJIN GREWIN TECHNOLOGY CO.,LTD.**

Web:www.grewin-tech.com WhatsApp:+86-13072088960

Email:salesmanager@grewin-tech.com

## Product description:

Medical Toroidal transformer:

Medical Equipment: Beyond the Toroidal Transformer has a common transformer function, its anti-electric strength and resistance to damp heat capacity far higher than the national standards and industry standards.

Additionally oriented towards the requirements of EN60601.Safety Temperature Limiter recommended security Value specified.

In many cases with statically shield winding to discharge capacitively coupled interferences, or to monitor the insulation.Especially low leakage current, which clearly under-runs the required norms( $\ll 5$  mA ).

Strengthened or enhanced insulation. At minimum equipped with basic insulation eightened creepage distance and sparking distance in air. Reduced inrush current.

## Features:

They should pay attention to the air clearance, leakage current, test voltage etc. We use the advanced machine to make sure the windings are very good performance. It should avoid the cables ' broken during the production.All the wire harnesses, product enclosures etc whould be treated very carefully.

## Application:

Medical grade isolation transformers are installed in medical devices used in hospitals, medical research facilities, and biomedical companies throughout the world. Our medical toroidal transformers are strictly monitored under safety rules, guidelines and governing laws.

### **NOTICE:**

**Toroidal transformer series products can be customer -made according to customers' request.**

**If necessary, please contact us.**